


2x4 WOOD MEMBER SUSPENSION METHOD.
ATTACHED TO EXISTING SLAB WITH HARDENED
NAIL. SUSPEND CHANNEL WITH
WIRE TIE FROM REBAR CLIPS.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'A' & 'B' 4' LOAD APPLICATION FOR CONCRETE / WOOD MEMBER SUSPENSION METHOD.

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.

TYPICAL 5" PRO SERIES INSTALLATION


CLASS "C" 6" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ ASPHALT.



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

N. T. S.

2x4 WOOD MEMBER SUSPENSION METHOD.
ATTACHED TO EXISTING SLAB WITH HARDENED
NAIL. SUSPEND CHANNEL WITH
WIRE TIE FROM REBAR CLIPS.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS "D" 8" LOAD APPLICATION FOR CONCRETE / WOOD MEMBER SUSPENSION METHOD.

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS "D" 8" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ PAVERS.

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS "D" 8" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD.

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.


TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'D' 8" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ ASPHALT.



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

N.T.S.




SECTION AT 5" PRO SERIES

NDS # 3P05 COUPLING OR 4P05
COUPLING TO 3" OR 4" BTM.
OUTLET.
3" OR 4" PVC PIPE BY OTHERS

TYPICAL 5" PRO SERIES BTM. OUTLET

3" OR 4" PVC COUPLING TO BTM. OUTLET CONNECTION.

N.T.S.



NDS 5" PRO SERIES #8II CHANNEL
END OUTLET W/ U.V. INHIBITOR


NDS # 4P05 4" COUPLING

NDS # 4P03 4" 45 ELBOW

4" PVC BY OTHERS.


NDS 5" PRO SERIES™ CHANNEL #8II 4" END OUT.

N.T.S.



NDS 5" PRO SERIES™ CHANNEL #811 3" END OUT.

N.T.S.



NOTE:


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.

TYPICAL 5" PRO SERIES INSTALLATION



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS "A" & "B" 4" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ PAVERS.

N.T.S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'A' & 'B' 4" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD.

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.

TYPICAL 5" PRO SERIES INSTALLATION


CLASS 'A' & 'B' 4" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ ASPHALT.



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

N.T.S.

2x4 WOOD MEMBER SUSPENSION METHOD.
ATTACHED TO EXISTING SLAB WITH HARDENED
NAIL. SUSPEND CHANNEL WITH
WIRE TIE FROM REBAR CLIPS. 



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'C' 6' LOAD APPLICATION FOR CONCRETE / WOOD MEMBER SUSPENSION METHOD.

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.


TYPICAL 5" PRO SERIES INSTALLATION

CLASS "C" 6" LOAD APPLICATION FOR CONCRETE / FORM BOARD SUSPENSION METHOD



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

N. T. S.



NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES
1-888-825-4716
techservice@ndspro.com

TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'C' 6" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ PAVERS.

N. T. S.

